

REST API for the In-Path Settings and Rules v1.0

Copyright © Riverbed Technology Inc. 2024

Created Jan 16, 2024 at 02:01 PM

Resource: global_setting

Global in-path settings

```
http://{device}/api/sh.inpath/1.0/global_setting
```

JSON

```
{  
  "link_state_propagation": boolean  
}
```

Property Name	Type	Description	Notes
<i>global_setting</i>	<i><object></i>	Global in-path settings	Required properties: [link_state_propagation];
<i>global_setting.link_state_propagation</i>	<i><boolean></i>	Link State Propagation - Enable to shorten the recovery time of a link failure in physical in-path deployments. Link state propagation (LSP) communicates link status between the devices connected to the Steelhead appliance. When you enable this feature, RiOS monitors the link state of each Steelhead appliance LAN-WAN pair.	

Links

global_setting: get

```
GET http://{device}/api/sh.inpath/1.0/global_setting
```

Response Body

Returns a [global_setting](#) data object.

global_setting: set

```
PUT http://{device}/api/sh.inpath/1.0/global_setting
```

Request Body

Provide a [global_setting](#) data object.

Response Body

Returns a [global_setting](#) data object.